


16-2531 Race Trim Hydraulic Pedal Assembly

When installing your pedal assembly you may chose to install a shaft pin to stop the shaft from rotating within the Pedal Base.

1. Determine desired position of Throttle Pedal
2. Drill a 3/16" hole thru shaft using the pre-drilled holes in the Pedal Base as a fixture
3. Press/Tap the Shaft Pin (attached) through the Pedal Base and Pedal Shaft




99-3999-0

16-2531 Race Trim Hydraulic Pedal Assembly

When installing your pedal assembly you may chose to install a shaft pin to stop the shaft from rotating within the Pedal Base.

1. Determine desired position of Throttle Pedal
2. Drill a 3/16" hole thru shaft using the pre-drilled holes in the Pedal Base as a fixture
3. Press/Tap the Shaft Pin (attached) through the Pedal Base and Pedal Shaft



99-3999-0