

## 17-2880 Narrow Oil Sump Instructions

### PREPARE THE ENGINE BY DRAINING THE OIL AND REMOVING THE STOCK OIL SUMP PLATE

1. **Clean the sump and all the parts thoroughly.** Any foreign material in the oil sump may cause engine damage.
2. Chose the oil pickup extension that fits your engine (**see figure 1**). You will need to cut 1¼" off the tip of the extension (**see figure 2**).
3. Secure the extender tube to the oil pickup with the hose clamp provided in this kit (**see figure 3**).
4. Install one gasket and align the sump over the studs on the engine case. Use the nuts and washers supplied to secure the sump to the engine case.
5. Install the gasket to the bottom of the sump and secure the sump cover in place using the nuts and washers.



Figure 1



Figure 2



Figure 3

0917/99-4450

## 17-2880 Narrow Oil Sump Instructions

### PREPARE THE ENGINE BY DRAINING THE OIL AND REMOVING THE STOCK OIL SUMP PLATE

1. **Clean the sump and all the parts thoroughly.** Any foreign material in the oil sump may cause engine damage.
2. Chose the oil pickup extension that fits your engine (**see figure 1**). You will need to cut 1¼" off the tip of the extension (**see figure 2**).
3. Secure the extender tube to the oil pickup with the hose clamp provided in this kit (**see figure 3**).
4. Install one gasket and align the sump over the studs on the engine case. Use the nuts and washers supplied to secure the sump to the engine case.
5. Install the gasket to the bottom of the sump and secure the sump cover in place using the nuts and washers.



Figure 1



Figure 2



Figure 3

0917/99-4450

## 17-2880 Narrow Oil Sump Instructions

### PREPARE THE ENGINE BY DRAINING THE OIL AND REMOVING THE STOCK OIL SUMP PLATE

1. **Clean the sump and all the parts thoroughly.** Any foreign material in the oil sump may cause engine damage.
2. Chose the oil pickup extension that fits your engine (**see figure 1**). You will need to cut 1¼" off the tip of the extension (**see figure 2**).
3. Secure the extender tube to the oil pickup with the hose clamp provided in this kit (**see figure 3**).
4. Install one gasket and align the sump over the studs on the engine case. Use the nuts and washers supplied to secure the sump to the engine case.
5. Install the gasket to the bottom of the sump and secure the sump cover in place using the nuts and washers.



Figure 1



Figure 2



Figure 3

0917/99-4450