



## Instructions for EMPI #9599/9601 Sway Bar Kit

### KIT CONTENTS:


- 1) Sway Bar
- 2) Sway Bar Bushings
- 2) Sway Bar Nuts

### PREPARATION

Raise the front of the car and support it with jack stands. Prior to removing the stock sway bar inspect the trailing arm bushings for wear and replace if necessary. For optimum suspension performance replace the stock rubber bushings with urethane bushings available through your EMPI dealer.

### INSTALLATION

Remove the two nuts that hold the sway bar onto the trailing arms and the four bolts that hold the bushing clamps to the frame head. Remove the clamps from the bushings and pull the sway bar out of the trailing arms. Install the new sway bar in the reverse order using the new urethane sway bar bushings included. Torque the sway bar nuts to 22ft. lbs. On 71-73 models torque the clamp bolts to 14ft. lbs. and on 74-79 models torque the clamp bolts to 29ft. lbs. It is recommended that after any front suspension work that the alignment be checked.



99-4134-0/1103



## Instructions for EMPI #9599/9601 Sway Bar Kit

### KIT CONTENTS:


- 1) Sway Bar
- 2) Sway Bar Bushings
- 2) Sway Bar Nuts

### PREPARATION

Raise the front of the car and support it with jack stands. Prior to removing the stock sway bar inspect the trailing arm bushings for wear and replace if necessary. For optimum suspension performance replace the stock rubber bushings with urethane bushings available through your EMPI dealer.

### INSTALLATION

Remove the two nuts that hold the sway bar onto the trailing arms and the four bolts that hold the bushing clamps to the frame head. Remove the clamps from the bushings and pull the sway bar out of the trailing arms. Install the new sway bar in the reverse order using the new urethane sway bar bushings included. Torque the sway bar nuts to 22ft. lbs. On 71-73 models torque the clamp bolts to 14ft. lbs. and on 74-79 models torque the clamp bolts to 29ft. lbs. It is recommended that after any front suspension work that the alignment be checked.



99-4134-0/1103